


ENGINE MOUNT POSITIONING BOLTS AND HEIGHT ADJUSTMENT NUTS MAY WORK LOOSE RESULTING IN MISALIGNMENT.
CHECK ALL DRIVELINE FASTENERS FOR TIGHTNESS AT REGULAR INTERVALS.

ANTARES 44 SUPPORT DRIVELINE SERVICE SP-04-10 SHEET 1 OF 2

NEW SHAFT STRAIGHTNESS TOLERANCE GUIDELINES



NOTE: RUNOUT DUE TO A BENT SHAFT OR DAMAGED COUPLING IS READILY APPARENT WHEN ROTATED BY HAND, MIS-ALIGNMENT INDUCED RUNOUT IS NOT

BEARINGS ARE COMPOSED OF BRONZE OUTER SHELL AND INNER GROOVED RUBBER ELEMENT. FIT TO SHAFT IS NEVER TIGHT, A MINIMUM RUNNING CLEARANCE OF .011" (3MM) IS REQUIRED TO PERMIT FLUID INTERFACE. NORMAL LONGEVITY IS SEVERAL SEASONS. REPLACE BY REMOVING SHAFT AND CUTTING THROUGH BEARING SHELL LONGITUDINALLY FROM THE INSIDE WITH HACKSAW BLADE. NEW BEARING PRESSES IN.

BEARINGS MAY BE QUICKLY DAMAGED BY FISHING LINE WRAP, RUBBER INSERT WILL BE CUT AWAY CREATING EXCESSIVE CLEARANCE AND VIBRATION. ANTARES 44 SUPPORT DRIVELINE SERVICE SP-04-10 SHEET 2 OF 2

ISSUED MARCH 29, 2011 FIRST VESSEL USED 44XX